

Husqvarna FS400LV

Pièces de rechange

Spare parts

Ersatzteile

Piezas de repuesto

Ricambi


Onderdelen

Reservdelar


Peças sobresselentes

No.	Pos.	Description	No.	Pos.	Description
115 030 720	B	IPL, FS400LV, 8 languages - EU	543 045 853	F	STICKER, SAFETY
115 030 730	B	IPL, FS400LV, 3 languages - US	543 045 871	F	Sticker, Stop
115 030 820	B	OM, FS400LV, 8 languages - EU	543 045 882	D	STICKER, SAFETY
115 030 830	B	OM, FS400LV, 3 languages -US	543 045 904	B	Wrench, forged 16/18, DIN895
502 082 901	A	Kit, blade guard D450	543 045 932	D	Roller
502 232 401	F	CABLE FS400LV	543 045 949	E	WHEEL ALU 125/41
502 287 901	H	BUSHING,ARTICULATION	543 045 951	B	WHEEL ALU200/51, LM 60 RAB 20
502 851 901	C	Kit, US flanges	543 046 068	B	RUBBER STRIP
502 852 401	C	Kit, blade shaft with US flanges	543 046 203	B	SPRING, FOR WRENCH
504 068 501	B E	CONSOLE, NEW STOP SWITCH	543 046 570	C	BLADE SHAFT, FS400LV
504 068 901	B E	DECAL, CONSOLE FS400LV	543 046 571	C	PULLEY, BLADESHAFT
504 069 101	D	Pointer, W/O roller, zincplated	543 046 572	F	PULLEY, ENGINE
504 069 201	A D	Kit, pointer with roller	543 046 633	B D E	WASHER 10,2x20x6
504 204 501	E	Grease nipple M8x1.00	543 046 700	D	WATERING FORK
539 300 500	F	ENGINE GX390 C9 13HP, HONDA	543 047 841	F	EXHAUST CAP HONDA
542 045 640	A	Filter, washer	543 047 852	F	KEY, SPARK PLUG
542 139 537	A	Valve, 1/2 with clamp	543 049 899	A	Kit, water tank
542 202 075	D	SPACER	543 066 184	F	OIL ENGINE PLATE, FS400LV
542 202 106	D	WASHER, POINTER	543 066 185	F	ENGINE PLATE, FS400LV
542 202 151	F	OIL DRAIN ASSY	543 068 111	C	Kit, blade shaft w/o flanges
542 202 308	A	Fitting, Swivel 3/4, 1/2 male NPT	543 068 112	C	Kit, EU flanges
542 202 309	F	STOP SWITCH	543 070 021	C	Kit, blade shaft with EU flanges
542 202 315	A	Kit, water supply, US	543 071 267	E	Sticker, Up and down, plunging,
542 202 321	A	Fitting, 1/2 m to D12 hose	543 074 515	E	POINTER, HEIGHT ADJUST, FS400LV
543 040 217	E	WASHER, 20 (D40-D21)X3	543 074 519	E	HEIGHT ADJUSTMENT, FS400LV
543 041 959	E	HOLDING CLAMP	543 074 526	E	GAS SPRING FIXING, FS400LV
543 042 515	B	WHEEL AXLE	543 076 293	E	GAS SPRING 1150 N
543 042 527	F	CABLE	543 076 294	E	HANDWHEEL D/201
543 042 540	F	TIGHTENING PLATE, FS400LV	543 076 329	E	WASHER 21X37X4 NYLON
543 042 861	E	SCREW AXLE, HEIGHT ADJ.	543 076 651	E	BLOCK HANDWHEEL, FS400LV
543 042 862	C	FLANGE, OUTER, FS450F/FS400LV	543 077 344	C	VIS A EMBASE H12X175 A, GAUCHE
543 042 875	D	MUD FLAP, FS450F/FS400LV	543 079 619	E	STICKER SECTOR FS400LV, D/450
543 043 875	H	SPACER	543 079 629	E	ADJUSTING SUPPORT FS400LV
543 044 720	H	WASHER L12	543 080 054	B	Silent block 40/28-3/M8
543 044 732	B D E	WASHER, SPRING 23X10.2X1	543 850 037	D	Sticker, Blade direction
543 044 757	E	NUT, M20 THIN	543 850 103	B	Rivet, 4x8 alu
543 044 766	E	Nut, M8x125, Ballhead	543 850 293	H	BUSHING, NYLON
543 044 769	D	ECROU TWOLOK M10	543 850 344	A	CLIP, HOSE
543 044 772	E	NUT M20 H20	543 850 351	F	Clamp, oil drain
543 044 782	C	KEY 5x5x20	543 850 352	E	Washer, spring 16x21
543 044 796	C	KEY 8x7x63	543 850 353	C	FLANGE, INNER
543 044 864	H	RIVET 4,8 X 9 STAINLESS	544 949 601	D	Pointer, simple, zincplated
543 044 964	F	BELT 633 PK 12, (FS400C/TN-CS),	544 949 801	B	Protective plate, FS350/400, orange
543 045 044	E	BEARING FY TB 20 TF	544 949 901	B	Lift bail, FS350/400, orange
543 045 052	C	BEARING FY TB 25 TF	544 950 001	B	Support, watertank F350/400, orange
543 045 099	F	CLIP, HOSE	544 950 101	B	Belt guard, FS350/400, grey
543 045 292	F	Switch, A COSSES	544 950 301	B	Frame, FS350/400, orange
543 045 539	D	VALVE 1/2" MALE/FEMALE	544 950 401	E	Carriage, height adjustment FS400LV
543 045 560	D	O-RING, D14	544 950 501	B E	Side panel, right FS400LV, orange
543 045 561	D	FLANGE NUT Clamp washer, 1/2 -14.2	544 950 604	B	Side panel, left FS400LV, orange
543 045 599	A	Cap, water tank	544 950 701	B E	Console, FS350/400, grey
543 045 610	D	ADAPTER, QUICK COUPLING	544 950 901	D	Blade guard, D 450, grey
543 045 612	A D	QUICK COUPLING, BRASS	544 951 001	B	Arm, lower right FS350/400, orange
543 045 617	B	STRAP, ELASTIC	544 951 101	B	Arm, lower left FS350/400, orange
543 045 654	B	HANDLE ANTIVIBRATION 25	544 951 201	B	Handle, anti vibration, grey
543 045 788	F	STICKER, NOISE 108dB	544 951 301	B	Kit, handle, anti vibration

No.	Pos.	Description	No.	Pos.	Description
722 781 803	B	Rivet, 3.2x6.7 alu			
722 794 402	D	Rivet, 4x12.1 alu			
725 229 571	A	Screw, M4x20 Hex FT			
725 236 661	F	SCREW, M6x12 HEX, SELF TAPPED			
725 236 671	D	SCREW, M6x12 hex FT			
725 244 771	B	Screw, M8x12 hex FT			
725 245 171	B E	Screw, M8x20 hex FT			
725 249 171	B E	Screw, hex M10X20			
725 249 371	B H	Screw, M10x25 hex FT			
725 249 571	B C E	SCREW, M10X30 HEX FT			
725 249 771	B D E	SCREW, M10X35 HEX FT			
725 249 971	E H	SCREW, M10X40 HEX FT			
725 250 171	B	SCREW, M10X50 HEX FT			
725 250 251	F	Screw, M10x55 hex PT			
725 250 551	D	Screw, M10x70 hex PT			
725 251 351	D	SCREW, M10X110 HEX PT			
725 251 571	H	SCREW, M10X120 HEX FT			
725 253 471	B	SCREW, M12X25 HEX FT			
725 253 671	H	SCREW, M12X30 HEX FT			
725 536 801	D	Screw, inhex M6x16			
725 545 101	E	SCREW, M8X20 INHEX			
728 744 505	C F	Screw, set M8x10 inhex, sharp end			
731 231 801	E	Nut, M8			
731 232 001	B D E H	Nut, M10			
731 711 851	E	NUT, M8 WITH WASHER			
732 211 801	B1	Nut, nyloc M8			
732 251 201	A	Nut, Nyloc M5			
732 252 001	BCDEFH	Nut, nyloc M10			
734 113 601	A	Washer, 4			
734 115 201	D	Washer, 6			
734 116 301	B E	Washer, 8			
734 117 201	B C D E	Washer, 10			
734 117 441	BDEFH	Washer, L10			
734 117 801	B	Washer, 12			
735 113 601	A	Washer, Lock 4			
735 116 401	E	Washer, lock 8			




544 951 301 =>




***compl 543 070 021 [EU]**
***compl 502 852 401 [US]**


***543 068 111 =>**




OPTION / OPTIONAL [EU]




502 082 901




504 069 201






HONDA GX 390 **ROBIN EH 41 DU**



543 070 038 (1) **5,5 CV TRI 400V**





www.husqvarnacp.com